


# CDUP 1200 CLASSROOMS AUDIO / VISUAL GUIDE

Press Jayhawk on main page to begin

## Need Help?

Please contact KU IT at

# 785-864-8080



**ShareLink:** The ShareLink allows you to connect your laptop or mobile device “wirelessly” to the display. Select this button and follow the onscreen instructions.

**LAPTOP:** Selecting the laptop button will route a laptop to the room display. You can connect your laptop using the provided VGA or HDMI cables at the podium.

**Rack PC:** Selecting the PC button will route the room PC to the display. You may also have to turn on the computer by pressing its main power button.

**Blu-ray:** Selecting Blu-ray will route the podium Blu-ray player to the room display.

**Doc Cam:** Selecting the Doc Cam button will route the Document Camera to the room display.

**Presentation Cam:** Room camera can be displayed on screen and used through the room PC for lecture capture and web conferencing.

### Instructors:

Please log in using your KU Online ID and password.

### Don't forget to log out.

To log out, double click the log out icon on the PC desktop.

**If another class does not immediately follow yours, please shut down the system. (System off)**



**KU** INFORMATION  
TECHNOLOGY  
The University of Kansas

[technology.ku.edu](http://technology.ku.edu)

### Need help?

Classroom Support: 785-864-1200

Customer Service Center: 785-864-8080 or

[itcsc@ku.edu](mailto:itcsc@ku.edu)

Follow us on Twitter  @KUTechnology